



Electric Motor Testing Tip of the Week

revolutionizing *electrical* reliability

January 7, 2008

Installation of MTAP2 CT's

When installing the CT's for MTAP2's, the length of the wiring from the MTAP CT's to the circuit board may vary. Although a maximum length has not been determined, a minimum size and type of wire is as follows:

- you must use 22 gauge wire or larger
- it is recommended that you use a shielded twisted pair

Using this type of wire will allow you to extend the length of your CT connections 50 feet or more.

You are invited to submit an Electric Motor Testing Tip of your own and receive a free PdMA mug or hat if we publish it! Contact Lou at 813-621-6463 ext. 126 or lou@pdma.com.

Copyright 2007 PdMA Corporation. All rights reserved. The PdMA Tip of the Week is produced by PdMA. PdMA shall not be liable for any errors or delays in the content, or for any actions taken in reliance thereon.