



Electric Motor Testing Tip of the Week

revolutionizing *electrical* reliability

March 20, 2006

Motor Rotation

Check for fan or pump motor rotation when testing offline with the MCE. Fans may continue to slowly rotate due to drafting in the Plenum. Pumps that are connected to a common header may continue to rotate if other pumps connected to the header are operating. This will adversely affect the Standard Test results, possibly creating higher than normal resistive and inductive imbalances.

Submitted by: Roger Hauglie – Pfizer – Kalamazoo, Michigan

Congratulations Roger!

You are invited to submit an Electric Motor Testing Tip of your own and receive a free PdMA mug or hat if we publish it! Contact Lou Martindale at 813-621-6463 ext. 126 or lou@pdma.com.

Copyright 2006 PdMA Corporation. All rights reserved. The PdMA Tip of the Week is produced by PdMA. PdMA shall not be liable for any errors or delays in the content, or for any actions taken in reliance thereon.